

Spare Parts List for WasteCaddy

500151-410 Standard Transaxle

300174 140Amp Controller

300183 8" Swivel Caster

500404 5" Swivel Caster

500137 Handle Bar Bushing

500140 Handle Bar Gear

500296 Torsion Spring

500139 Pot Gear

500152 Handle Bar Grip

500129-10 Tire & Rim Assy Snow Hog

500187 E-Stop Switch

500145-01 Key Switch Assy.

500145-02 Extra Set of Keys

500147 10 Amp Circuit Breaker

500149 36VDC Contactor

500519-071 Onboard Charger Promariner

500142 Pot & Harness Assy.

500345-02 100 Amp Fuse

500345-03 100 Amp Fuse Holder

500125 Voltmeter

500143-02 Main Wire Harness 140A

500870-03 Controller Adapter Harness

500354 E-Stop Wire Harness

500349-01 Slow Speed Harness

500356-012 Knob for Slow Speed Pot

500151-04 Lug Nut

500359-051 Snap Pin

500305-03 Hood Latch

590197-01 WC Main Plate Painted